

# FLX CONSOLE

## ACCESSORIES & SPARE PARTS LIST

The following accessories and spare parts are available to order for the FLX Console:

### ACCESSORIES

Part Code	Name
5630-000043-00	FLX dust cover
9805-000058-00	FLX flightcase
0020-000016-00	ZerOS Wing (with USB connection, feet & brackets)
9805-000059-00	ZerOS Wing flightcase

### SPARE PARTS

Part Code	Name
0095-000163-00	FLX Carrier PCBA
0550-000218-00	FLX Q7 Module Cortex A9
0095-000164-00	FLX User Interface PCBA
0095-000165-00	FLX Encoder Wheels PCBA
0095-000166-00	FLX MFFs PCBA
5620-000611-00	FLX Plastic Side (2 required per desk)
0021-000004-00	FLX Internal PSU (60W 15V)
0095-000168-00	FLX Touchscreen Assembly
5110-000039-00	2m Mains Lead - UK Plug to Neutrik powerCON TRUE1 TOP
5110-000040-00	2m Mains Lead - Schuko to Neutrik powerCON TRUE1 TOP
5630-000030-00	FLX Button Cap Set
5356500	Keypad (Cherry) - no LED

<b>0095-000170-00</b>	Keyswitch (Cherry) - red LED
<b>0095-000171-00</b>	Keyswitch (Cherry) - blue LED
<b>0095-000172-00</b>	Keyswitch (Cherry) - white LED
<b>6050-000013-00</b>	Black button (Wide) - single white LED
<b>1722-000007-00</b>	45mm Fader (FLX: Grand Master, FLX S: All)
<b>1722-000010-00</b>	60mm Fader - long tang (Master Playback)
<b>1722-000006-00</b>	60mm Fader - short tang (MFFs)
<b>5442000</b>	Soft Touch Fader Cap (Wide) - Black/White
<b>4905000</b>	3V Lithium Coin Cell Battery - 200mAh
<b>3194000</b>	5pin XLR socket (plastic, right angled, PCB mount)