



DMX	Parameter	Range %	Defaults*	Description
9	Strobe Speed	0 - 100%	0	Controls strobe rate from slowest (DMX 0) to fastest (DMX 255)
10	Strobe Control	0 - 255 0 - 5 6 - 10 11 - 15 16 - 20 21 - 25 26 - 255	0 → → → → → →	Control Channel for strobing functions. Open Closed Normal Strobe Random Strobe Random Sync Reserved Values
11	Intensity Timing	0 - 100%	255	Allows for timing control of intensity. Channel should default to 255 for smoothest actions using console and/or manual fades. - See Timing Chart for more details.
12	Color Timing	0 - 100%	255	Allows for timing control of colors. Channel should default to 255 for smoothest actions using console and/or manual fades. - See Timing Chart for more details.
13	Focus Timing	0 - 100%	255	Allows for timing control of zoom.
14	Control	0 - 100%	0	Please refer to the control channel detail define.
15	Red*	0 - 100%	0	8bit control of Red LEDs from 0 to full.
16	Green *	0 - 100%	0	8bit control of Green LEDs from 0 to full.
17	Blue*	0 - 100%	0	8bit control of Blue LEDs from 0 to full.
18	White*	0 - 100%	0	8bit control of White LEDs from 0 to full.

\* Adding additional color group expands Dmx map from this point in blocks of RGBW