

RGBW 16bit Mode			
DMX CHANNEL	(G1) 1 Group Mode (Default Mode)	(G3) 3 Group Mode	(G12) 12 Group Mode
1	Pan High	Pan High	Pan High
2	Pan Low	Pan Low	Pan Low
3	Tilt High	Tilt High	Tilt High
4	Tilt Low	Tilt Low	Tilt Low
5	Pan Control	Pan Control	Pan Control
6	Tilt Control	Tilt Control	Tilt Control
7	Intensity High	Intensity High	Intensity High
8	Intensity Low	Intensity Low	Intensity Low
9	Color Pre-set	Color Pre-set	Color Pre-set
10	Strobe Rate	Strobe Rate	Strobe Rate
11	Strobe Duration	Strobe Duration	Strobe Duration
12	Intensity Timing	Intensity Timing	Intensity Timing
13	Color Timing	Color Timing	Color Timing
14	Focus Timing (Pan and Tilt)	Focus Timing (Pan and Tilt)	Focus Timing (Pan and Tilt)
15	Control	Control	Control
16	Red - High	Red - High - Group 1	Red - High - 1
17	Red - Low	Red - Low - Group 1	Red - Low - 1
18	Green - High	Green - High - Group 1	Green - High - 1
19	Green - Low	Green - Low - Group 1	Green - Low - 1
20	Blue - High	Blue - High - Group 1	Blue - High - 1
21	Blue - Low	Blue - Low - Group 1	Blue - Low - 1
22	White - High	White - High - Group 1	White - High - 1
23	White - Low	White - Low - Group 1	White - Low - 1
24		Red - High - Group 2	Red - High - 2
25		Red - Low - Group 2	Red - Low - 2
26		Green - High - Group 2	Green - High - 2
27		Green - Low - Group 2	Green - Low - 2
28		Blue - High - Group 2	Blue - High - 2
29		Blue - Low - Group 2	Blue - Low - 2
30		White - High - Group 2	White - High - 2
31		White - Low - Group 2	White - Low - 2
32		Red - High - Group 3	Red - High - 3
33		Red - Low - Group 3	Red - Low - 3
34		Green - High - Group 3	Green - High - 3
35		Green - Low - Group 3	Green - Low - 3
36		Blue - High - Group 3	Blue - High - 3
37		Blue - Low - Group 3	Blue - Low - 3
38		White - High - Group 3	White - High - 3
39		White - Low - Group 3	White - Low - 3
40		Red - High - 4	Red - High - 4
41		Red - Low - 4	Red - Low - 4
42		Green - High - 4	Green - High - 4
43		Green - Low - 4	Green - Low - 4
44		Blue - High - 4	Blue - High - 4
45		Blue - Low - 4	Blue - Low - 4
46		White - High - 4	White - High - 4
47		White - Low - 4	White - Low - 4
48		Red - High - 5	Red - High - 5
49		Red - Low - 5	Red - Low - 5
50		Green - High - 5	Green - High - 5
51		Green - Low - 5	Green - Low - 5
52		Blue - High - 5	Blue - High - 5
53		Blue - Low - 5	Blue - Low - 5
54		White - High - 5	White - High - 5
55		White - Low - 5	White - Low - 5
56		Red - High - 6	Red - High - 6
57		Red - Low - 6	Red - Low - 6
58		Green - High - 6	Green - High - 6
59		Green - Low - 6	Green - Low - 6
60		Blue - High - 6	Blue - High - 6
61		Blue - Low - 6	Blue - Low - 6
62		White - High - 6	White - High - 6
63		White - Low - 6	White - Low - 6
64		Red - High - 7	Red - High - 7
65		Red - Low - 7	Red - Low - 7
66		Green - High - 7	Green - High - 7
67		Green - Low - 7	Green - Low - 7
68		Blue - High - 7	Blue - High - 7
69		Blue - Low - 7	Blue - Low - 7
70		White - High - 7	White - High - 7
71		White - Low - 7	White - Low - 7
72		Red - High - 8	Red - High - 8
73		Red - Low - 8	Red - Low - 8
74		Green - High - 8	Green - High - 8
75		Green - Low - 8	Green - Low - 8
76		Blue - High - 8	Blue - High - 8
77		Blue - Low - 8	Blue - Low - 8
78		White - High - 8	White - High - 8
79		White - Low - 8	White - Low - 8
80		Red - High - 9	Red - High - 9
81		Red - Low - 9	Red - Low - 9
82		Green - High - 9	Green - High - 9
83		Green - Low - 9	Green - Low - 9
84		Blue - High - 9	Blue - High - 9
85		Blue - Low - 9	Blue - Low - 9
86		White - High - 9	White - High - 9
87		White - Low - 9	White - Low - 9
88		Red - High - 10	Red - High - 10
89		Red - Low - 10	Red - Low - 10
90		Green - High - 10	Green - High - 10
91		Green - Low - 10	Green - Low - 10
92		Blue - High - 10	Blue - High - 10
93		Blue - Low - 10	Blue - Low - 10
94		White - High - 10	White - High - 10
95		White - Low - 10	White - Low - 10
96		Red - High - 11	Red - High - 11
97		Red - Low - 11	Red - Low - 11
98		Green - High - 11	Green - High - 11
99		Green - Low - 11	Green - Low - 11
100		Blue - High - 11	Blue - High - 11
101		Blue - Low - 11	Blue - Low - 11
102		White - High - 11	White - High - 11
103		White - Low - 11	White - Low - 11
104		Red - High - 12	Red - High - 12
105		Red - Low - 12	Red - Low - 12
106		Green - High - 12	Green - High - 12
107		Green - Low - 12	Green - Low - 12
108		Blue - High - 12	Blue - High - 12
109		Blue - Low - 12	Blue - Low - 12
110		White - High - 12	White - High - 12
111		White - High - 13	White - High - 13

RGBW 8bIT MODE			
DMX CHANNEL	(G1) 1 Group Mode	(G3) 3 Group Mode	(G12) 12 Group Mode
1	Pan High	Pan High	Pan High
2	Pan Low	Pan Low	Pan Low
3	Tilt High	Tilt High	Tilt High
4	Tilt Low	Tilt Low	Tilt Low
5	Pan Control	Pan Control	Pan Control
6	Tilt Control	Tilt Control	Tilt Control
7	Intensity	Intensity	Intensity
8	Color Pre-set	Color Pre-set	Color Pre-set
9	Strobe Rate	Strobe Rate	Strobe Rate
10	Strobe Duration	Strobe Duration	Strobe Duration
11	Intensity Timing	Intensity Timing	Intensity Timing
12	Color Timing	Color Timing	Color Timing
13	Focus Timing (Pan and Tilt)	Focus Timing (Pan and Tilt)	Focus Timing (Pan and Tilt)
14	Control	Control	Control
15	Red -	Red - Group 1	Red - 1
16	Green -	Green - Group 1	Green - 1
17	Blue -	Blue - Group 1	Blue - 1
18	White -	White - Group 1	White - 1
19		Red - Group 2	Red - 2
20		Green - Group 2	Green - 2
21		Blue - Group 2	Blue - 2
22		White - Group 2	White - 2
23		Red - Group 3	Red - 3
24		Green - Group 3	Green - 3
25		Blue - Group 3	Blue - 3
26		White - Group 3	White - 3
27			Red - 4
28			Green - 4
29			Blue - 4
30			White - 4
31			Red - 5
32			Green - 5
33			Blue - 5
34			White - 5
35			Red - 6
36			Green - 6
37			Blue - 6
38			White - 6
39			Red - 7
40			Green - 7
41			Blue - 7
42			White - 7
43			Red - 8
44			Green - 8
45			Blue - 8
46			White - 8
47			Red - 9
48			Green - 9
49			Blue - 9
50			White - 9
51			Red - 10
52			Green - 10
53			Blue - 10
54			White - 10
55			Red - 11
56			Green - 11
57			Blue - 11
58			White - 11
59			Red - 12
60			Green - 12
61			Blue - 12
62			White - 12