

VL800 BeamLine Control Channel detail

DMX	Parameter	Range %	Defaults*	Description
x	Control	0 - 100%	0	Control Channel used for full fixture settings, lamp controls, and miscellaneous modes. Set discrete value of desired effect, wait >3 seconds, then set value to 0 (Idle).
			0 - 5	Idle (Default)
			6 - 10	Full Luminaire ReCal
			11 - 15	Reserves(Future use)
			16 - 20	Reserves(Future use)
			21-25	Fixture Shutdown
			26 - 30	Display-Menu On
			31 - 35	Display-Menu Off
			36 - 40	ReCal Position
			41 - 45	Reserved (Future use)
			46 - 50	Reserved (Future use)
			51 - 55	Reserved (Future use)
			56 - 60	Reserved (Future use)
			61 - 65	Reserved (Future use)
			66 - 70	Reset Fixture to Defaults
			71 - 75	Full Luminaire Reboot
			76 - 80	Fixture Status On/Off. This comand will enable to display to show fixture status for 5 min. After this time, display return fo default configerations. Repeating this command in les than 5 minutes will behave as a toggle
			81 - 85	Fan Auto*
			86 - 90	Fan off
			91 - 95	DIM Response_Incandescent_Off
			96 - 100	DIM Response_Incandescent_ON
			101 - 105	Dimming Curve_linear
			106 - 110	Dimming Curve_Square
			111 - 115	Reserved
			116 - 120	Dimming Curve_PL-Curve
			121 - 125	Calibration_OFF
			126 - 130	Calibration_ON
			131 - 255	Reserved (Future use)
				*Default Setting