

SUBJECT: VL500™ Wash Luminaire Software Update	SERIES: 500
DISTRIBUTION: Service Centers, End Users	STATUS: Routine

## Introduction

---

### Embedded Software Update

Software update **07/25/06** for **VL500™ Wash Luminaires** (all versions) is now available. This technical bulletin covers all changes in this new version.



**Note:** Vari-Lite suggests that all users replace their current VL500™ wash luminaire software with this version of software. Please see improvements below for further information.

For instructions on downloading and installing VARI\***LITE**<sup>®</sup> luminaire software, refer to technical bulletin LSW-002.

If you have any questions regarding this release or your VARI\***LITE**<sup>®</sup> product, please contact Vari-Lite Customer Service at 1-877-VARILITE (or +1-214-647-7880) or via e-mail at [customerservice@genlyte.com](mailto:customerservice@genlyte.com).

## Release Notes

---

### Improvements in New Version

#### VL500™ Wash Luminaires:

- Vari-Lite has made improvements to the calibration routine that executes:
  - During fixture start up, or:
  - When accessed via the luminaire's menu display, or:
  - Resetting with the control channel from the lighting control desk.
- During calibration, the luminaire's tilt calibration will fully home before pan calibration begins.
- While tilt is cycling through its calibration, a holding current is applied to pan to keep it stationary.

VARI\***LITE**<sup>®</sup>, VL500™, VL1000™, VL2000™, VL2500™, VL3000™, and VL3500™ are trademarks of Genlyte Thomas Group LLC